

73

"To show partiality is not good."

Printer Escape Codes

FEATURE	ESCAPE CODE	9 Pin	24 Pin
Pitch And Proportional Spacing			
Proportional On/Off	ESC p n	✓	✓
Print Enhancement			
Select NLQ or Draft	ESC x n	✓	✓
Expanded Print On/Off	ESC W n	✓	✓
Double High On/Off	ESC w n	✓	✓
Underlining On/Off	ESC - n	✓	✓
Select Super/Subscript	ESC S n	✓	✓
User Defined Character			
Select Character Set	ESC % n	✓	✓
Miscellaneous Codes			
Unidirectional On/Off	ESC U n	✓	✓
Half Speed On/Off	ESC s n	✓	✓
Print Style Selection			
Select Font: n = 0 Roman n = 1 San Serif n = 2 Courier n = 3 Prestige n = 4 Script n = 5 Ocr-B n = 6 Ocr-A n = 7 Orator n = 8 Orator S	ESC k n Available only with Multi-Font Module	✓ ✓ ✓	✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓
Character Style: n = 0 Normal n = 1 Outline n = 2 Shadow n = 3 Outline & Shadow	ESC q n		✓ ✓ ✓ ✓
Print Style Selection			
Master Select: n = 0 Pica n = 1 Elite n = 2 Proportional n = 4 Condensed n = 8 Emphasized n = 16 Double Strike	ESC ! n	✓ ✓ ✓ ✓ ✓ ✓	✓ ✓ ✓ ✓ ✓ ✓

844 A to Z of C

FEATURE	ESCAPE CODE	9 Pin	24 Pin
Print Style Selection			
n = 32 Double Wide		✓	✓
n = 64 Italic		✓	✓
n = 128 Underline		✓	✓
Select Score: n1 Must be 3 n2 Must be 0 m Must be 1 d1 = 1 Underscore d1 = 2 Strike-Through d1 = 3 Overscore d2 = 0 Cancel Selected Score d2 = 1 Single Line Continuous d2 = 2 Double Line Continuous d2 = 5 Single Line Broken d2 = 6 Double Line Broken	ESC (- n1 n2 m d1 d2		✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓
Line Spacing			
n/360-inch Spacing	ESC + n		✓
n/180-inch Spacing	ESC 3 n		✓
n/216-inch Spacing	ESC 3 n	✓	
n/60-inch Spacing	ESC A n		✓
n/72-inch Spacing	ESC A n	✓	
Immediate n/216 Feed	ESC J n	✓	✓
Immediate n/180 Feed	ESC J n	✓	
Reverse Feed n/216	ESC j n	✓	✓
Reverse Feed n/180	ESC j n		
Page Formatting			
Immediate Mode On/Off	ESC i n	✓	
Intercharacter Spacing	ESC SP n	✓	✓
Page Length in Lines	ESC C n	✓	✓
Page Length in Inches	ESC C NUL n	✓	✓
Skip Over Perforation	ESC N n	✓	✓
Set Left Margin	ESC I n	✓	✓
Set Right Margi	ESC Q n	✓	✓
Horizontal Tab Setting			
Horizontal Tab	HT	✓	✓
Horizontal Tab Stops	ESC D n1 n2..NUL	✓	✓
Set Tab Increment	ESC e NUL n	✓	✓
SET HTabs in Spaces	ESC f NUL n	✓	✓
Vertical Tab Setting			
Set Tab Stops	ESC B n1 n2..NUL	✓	✓
Set VFU Tab Channel	ESC b x n1 n2..NUL	✓	✓
Select VFU Tab Channel	ESC / x	✓	✓
Set Tab Increment	ESC e 1 n	✓	✓
Vertical Skip	ESC f 1 n	✓	✓
Set VTabs in Channel	ESC b c n1 n2...NUL	✓	✓
Set VTab Channel	ESC / n	✓	

FEATURE	ESCAPE CODE	9 Pin	24 Pin
Graphics			
Select Graphic Mode 8-Pin Graphics: m = 0 60 DPI m = 1 120 DPI m = 2 120 DPI Hi Spd m = 3 240 DPI m = 4 80 DPI m = 5 72 DPI m = 6 90 DPI m = 7 144 DPI	ESC * m n1 n2 data	✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓	✓ ✓ ✓ ✓ ✓ ✓ ✓
Select Graphics Mode 24-Pin Graphics: m = 32 60 DPI m = 33 120 DPI m = 38 90 DPI m = 39 180 DPI m = 40 360 DPI	ESC * m n1 n2 data		✓ ✓ ✓ ✓ ✓
Individual Graphics Commands			
Single-Density 60 DPI Double-Density 120 DPI Hi-Speed Dbl. 120 DPI Quad. Density 240 DPI 9-Pin 60 DPI 9-Pin 120 DPI Reassign Graphics Mode	ESC K n1 n2 data ESC L n1 n2 data ESC Y n1 n2 data ESC Z n1 n2 data ESC ^ 0 n1 n2 data ESC ^ 1 n1 n2 data ESC ? n	✓ ✓ ✓ ✓ ✓ ✓ ✓	
Epson Extended Character Set			
Set to Epson Extended character set	ESC m 4	✓	✓
User Defined Characters			
Define User Defined Character Copy ROM to RAM Copy ROM to RAM n = 0 Roman n = 1 San Serif Select ROM CG Select Download CG	ESC & NUL n1 n2 a1 data ESC : NUL NUL NUL ESC : NUL n NUL ESC % 0 ESC % 1	✓ ✓ ✓ ✓ ✓	✓ ✓ ✓ ✓ ✓
Justification			
Justification: n = 0 Flush Left n = 1 Centering n = 2 Flush Right n = 3 Justified	ESC a n	✓ ✓ ✓ ✓ ✓	✓ ✓ ✓ ✓ ✓
Select Character Table			
Select Character Set: n = 0 Italic set n = 1 Graphic set n = 2 User-Defined Set Remap to 80h-FFh	ESC t n	✓ ✓ ✓ ✓	✓ ✓ ✓ ✓

